


**Intellitec's TouchLite** is a sensor pad activated control for outdoor lighting. When wired into an existing 12 Volt outdoor porch light, it provides 30 seconds of light to allow the user to find the door key and unlock the door in a darkened area.

**TouchLite** wires in parallel with the existing outdoor light switch. It will in no way interfere with the normal operation of the switch. It easily installs by drilling a 3/8" diameter hole through the coach wall and mounting the control unit on the inside and the sensor pad on the outside.

The sensor touch pad is of non-corrosive stainless steel, over-molded with clear plastic to allow the color of the surface to which it is mounted to show through.

**TouchLite** provides just enough time to allow you to find your keys on that dark night in a secluded camp ground. Just touch and go.





www.intellitec.com


P/N 53-00098-000 Rev. B 032119

## TouchLite TM

## Specifications:

Operating voltage Current output Lamp power Time Delay Quiescent Current Fits wall sizes 8 to 16 Volts DC 1.5 Amps Max 18 Watts Max 20 to 40 seconds 0.001 Amp typical 0.5 to 2.5 inches thick

## Wiring Diagram:





P/N 53-00098-000 Rev. B 032119