
## Touchlite TM

Intellitec's TouchLite<sup>™</sup> is a sensor pad activated control for outdoor lighting. When wired into an existing 12 Volt outdoor porch light, it provides 30 seconds of light to allow the user to find the door key and unlock the door in a darkened area.

TouchLite<sup>™</sup> wires in parallel with the existing outdoor light switch. It will in no way interfere with the normal operation of the switch. It easily installs by drilling a 3/8" diameter hole through the coach wall and mounting the control on the inside and the sensor pad on the outside.

The sensor touch-pad is of non-corrosive stainless steel, over molded with clear plastic to allow the color of the surface to which it is mounted to show through.

TouchLite<sup>™</sup> provides just enough time to allow you to find your keys on that dark night in a secluded camp ground. Just touch and go!



P/N 00-00098-000




## Touchlite TM

## **SPECIFICATIONS**

Part Number: 00-00099-000
Operating Voltage 8 - 16 Volts DC
Current output 1.5 Amps Max
Lamp power 18 Watts Max
Time Delay 20 - 40 seconds
Quiescent current 0.001 Amp typical
Fits wall sizes 0.5 - 2.5 inches thick

## **WIRING DIAGRAM**





**EXISTING 12V PORCH LIGHT CIRCUIT** 

P/N 53-000098-001 Rev D 032119