



# BATTERY MANAGER

## WIRING DIAGRAM

MAY 10, 1996



- "USE" SW
- "STORE" SW
- LED
- GROUND
- +24 V BATTERY
- LOAD (CONVERTER)
- BD RELAY "S" TERMINAL
- BD RELAY "I" TERMINAL
- IGNITION
- POWER GROUND



NOTE:  
IF 24 VOLTS IS PRESENT AT THE IGNITION INPUT (IGNITION IS "ON")  
THE VOLTAGE MONITOR AND "STORE" FUNCTIONS WILL BE DISABLED