

Cross- Reference for EMS Systems to Replacement EMS Part Numbers

Last Revised: 10/22/19

Suspect Part Number: All EMS product part numbers

Fault Symptom: Cross-reference for previous EMS systems to current replacement EMS part numbers

Associated Manual: See Below

Status of replacement parts: Active

This table provides the cross-reference information from previous EMS models and allow you to define the part numbers required to update to a current production EMS system. The instructions for upgrading and installing the new EMS system are part of the FAQ documents and are included as of the release of this document.

How to use table?

- 1) Find part number in either “Original Part Number” or “Current Production Part Number” column. The part number format is 10 digits where each digit is represented by ‘x’ as follows xx-xxxxx-xxx.
- 2) Once part number is located to a specific row, the replacement part number(s) needed are identified in the column heading as shown below:
 - a. “Original Part Number” column heading, look in the “Part Numbers for Replacement” and proceed to the specific row containing your part number.
 - b. “Current Production Part Number” column heading, look in the “Replacement Part Numbers for Current Production” and proceed to the specific row containing your part number.
- 3) The last column in the table provides reference documents which you will require in order to correctly configure the ‘shed’ of the managed loads. These documents may be downloaded from the Intellitec website, see URL below.

<https://www.intellitec.com/products/>

- 4) A current distributor list can also be found on the Intellitec website, see ULR.

<https://www.intellitec.com/distributors/>

Obsolete EMS Model number	Original Part Number	Part Numbers for Replacement	Current Production Part Number	Replacement Part Numbers for Current Production	Associated Product Installation Documents
EMS 500	00-00549-000, 00-00549-100	74-00912-000 00-00903-030 11-00903-000 11-00903-100 00-00703-000	00-00912-000	74-00912-000	53-00549-100 AND 53-00912-000
Model 620, Powerline System Winnebago	00-00633-x00, 00-00634-x00	00-00911-000 00-00903-250 11-00903-000 11-00903-100 00-00703-000	00-00911-000	EMS Board Only 00-00911-000 Display Only 00-00903-250	53-22100A100 AND 53-00911-000
Powerline 2000 Winnebago	00-00740-x00, 00-00757-x00	00-00911-000 00-00903-250 11-00903-300 11-00903-200	00-00911-000	EMS Board Only 00-00911-000 Display Only 00-00903-250	53-00740-100 AND 53-00911-000
Model 700*, 750* *Original Version	00-00683-000, 00-00684-100	00-00894-200 00-00903-150 11-00903-000 11-00903-100	00-00894-000	EMS Board Only 00-00894-200 Display Only 00-00903-150	53-00684-000 AND 53-00894-000
Model 760	00-00683-200, 00-00684-100	00-00894-200 00-00903-150 11-00903-000 11-00903-100	00-00894-000	EMS Board Only 00-00894-200 Display Only 00-00903-150	53-00684-000 AND 53-00894-000
Model 800* *Original Version	00-00683-300, 00-00684-100	00-00894-200 00-00903-150 11-00903-000 11-00903-100	00-00894-300	EMS Board Only 00-00894-200 Display Only 00-00903-150	53-00684-100 AND 53-00894-100
Model 850	00-00683-400, 00-00684-100	00-00894-200 00-00903-150 11-00903-000 11-00903-100	00-00894-300	EMS Board Only 00-00894-200 Display Only 00-00903-150	53-00684-100 AND 53-00894-100
Model 860	00-00683-500, 00-00684-100	00-00894-200 00-00903-150 11-00903-000 11-00903-100	00-00894-300	EMS Board Only 00-00894-200 Display Only 00-00903-150	53-00684-100 AND 53-00894-100
Model 900*, 960 *Original Version	00-00767-000, 00-00684-000	00-00894-600 00-00903-150 11-00903-000 11-00903-100	00-00894-600	EMS Board Only 00-00894-200/-700 Display Only 00-00903-150	53-00684-200 AND 53-00894-600
Model 1000, 1200, 1300	00-0997-x00, 00-00949-000	Call Intellitec Products			53-00997- 000/-200/-100