

Disconnect wire from positive battery terminal and isolate while performing installation

•Verify that the correct relay is used for the amperage requirements of the system

Hole size for switch: 0.866" or 22.0mm

Unplug switch from wire harness. Remove retaining nut from back of switch, insert connector through the hole drilled for switch, Re-attach retaining nut on back side.

CHG	ECL#	D	ESCRIPTION	BY	DATE	
INLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE DECIMAL STATE ANGLES .XX± .010 ±0° 30' .XXX± .005 A MATERIAL		INTELLITEC PRODUCTS, LLC. 1485 JACOBS RD DELAND, FL 32724	AND PROPRIETAR NEITHER THE DR THERON MAY BE INTELLITEC PROI	THESE DRAWINGS AND SPECIFICATIONS ARE CONFIDENTIAL AND PROPRIETARY TO INTELLITEC PRODUCTS, LLC. AND NEITHER THE DRAWINGS THEMSELVES NOR ANY INFORMATION THERON MAY BE USED WITHOUT THE WRITTEN PERMISSION OF INTELLITEC PRODUCTS, LLC.		
SEE NOTES		SCALE=N/A ERO#ECL 4842 DWN BY/DATE: MJS 6/21/16		APP. BY/DATE:		
FINISH SEE NOTE	PROJECT/TITLE SERV. MAN. BATTERY GUARD SY		SYSTEM 3A F	53-00660-40	-	REV A